Course and Section: N	Names:
	name:
Lenses ar	nd Mirrors
Answer all questions from	THE TEXT ON THE LINES BENEATH.
In this experiment you will study lenses ar doing so you will study the laws describing	nd mirrors by creating images on screens. By them.
1 Equipment	
• Optical bench	• Viewing screen
• Converging lens, diverging lens	• Mirror
• Light source (as an object)	• Half-screen
2 Procedure	
2.1 Converging lens	
	it thicker or thinner in the center? What do used as a magnifying glass? Try the lens both
lens to the image is defined to be the focinfinitely remote object are essentially para	hing infinitely far away, the distance from the all length. This is because the rays from an allel (to the optical axis) and thus converge at lens axis to the focal point is called the <i>focal</i>
Use the lens to form an image of "somethin optical bench and move the screen on the b	ng far away". To do this, place the lens on the bench until a sharp image is formed on it.

 $Focal\ length = \underline{\hspace{1cm}} cm$ 




Figure 1: Converging lens: For an object outside of the focal point a *real* inverted image is formed.

The equation relating the image and object distances of a thin lens is

$$\frac{1}{p} + \frac{1}{q} = \frac{1}{f} \,. \tag{1}$$

## 2.2 Image-Object Relationship of a Converging Lens

In this part, use the light box as the object; the lens will form an image of this box on the screen. Place the object and the screen at opposite ends of the bench such that the distance between them is 110 cm. Place a white sheet of paper in front of the white screen. Move the lens between them until a sharp image is formed on the screen. You should note that there are two positions for the lens which give sharp images. Why is that so?

Take measurements for each of these positions. Repeat these measurements for  $L=100\,\mathrm{cm}$  and  $L=90\,\mathrm{cm}$ . Record the distance p from the lens to the object and the distance q from the lens to the image. Also measure the height h' of the image and the height h of the object.

$$h = \underline{\hspace{1cm}} cm$$

L (cm)	p (cm)	q (cm)	h' (cm)	f (cm)	h'/h	q/p
110						
110						
100						
100						
90						
90						

Use equation (1) to calculate the *focal length* f from each set of data in the table and fill in that part of the table. What f, p and q are is also shown in figure 1.

_	$D_{0}$ wou	cot	consistent	779 11100	for	tho	focal	lonath	f	7
•	Do you	get	Consistent	varues	101	une	jocui	iengin	.) :	٠

•	Do these results	agree wit	h the foca	al length	you	found	in the	first	part c	of the	exper-
	iment?										

• Which method	do you think is t	he most accur	rate?			
Finally, look at the equal? If so, why?	last two columns	of the table.	Do you fin	d that the	two rat	tios are

## 2.3 Diverging Lens

A diverging lens will produce a virtual image of a real object. To observe this, place the lens on the optical bench about 20 cm from the light box. Move the screen on the bench, can you find the image on the screen? Now, look at the light box through the lens, can you see the image?

- Is this image smaller or bigger than the object?
- Is the image you are viewing inverted?
- Is it *virtual*?

• Is it located in *front* or in the *back* of the lens?




Figure 2: The diverging lens creates a virtual image which we cannot capture on a screen. Thus we have to add a converging lens.




Figure 3: A converging followed by a diverging lens. This way an upright real image is formed that can be captured on a screen.

In order to produce a real image by a diverging lens you also need to use a converging lens, see figure 3.

1. Start by forming a clear image on the screen using only the converging lens. Find the

distance of the object to the lens p. Using the thin lens equation, calculate distance of the image q formed by the converging lens

$$q = \underline{\qquad}$$
cm.

- 2. Insert the diverging lens between the image and the converging lens. Refer to the diagram for help.
- 3. Measure the distance d between the two lenses.

$$d = \underline{\qquad}$$
 cm.

The image created by the converging lens becomes the object for the diverging lens.

- 4. Move the diverging lens until a real image is produced on the screen.
- 5. Measure the "new" object distance p', with respect to the diverging lens. Take the difference between the two distances q and d.

$$p' = q - d =$$
\_\_\_\_\_\_ cm.

6. Measure the distance q' between the screen and the diverging lens

$$q' = \underline{\qquad}$$
cm.

7. Finally, find the focal length of the diverging lens using the thin lens equation for p', q' and f'. Note: In equation (2) the sign of p' has to be negative, since the image formed by the converging lens is behind the diverging lens.

$$\frac{1}{p'} + \frac{1}{q'} = \frac{1}{f'} \,. \tag{2}$$

Find the focal length f' of the diverging lens,

$$f' = \underline{\qquad}$$
 cm.